




Power Bank User Manual 移动电源说明书



Instructions

Power on/off: Power button is on the frontside. Short press it to start up, and the LED indicator will stay blue. Automatic shut-down is triggered when no interactions are made in 30 seconds.

Indicator Light: There're 4 LED indicators and each of them refers to 25% of the battery capacity. When the LED1 blinks fast, recharging is needed. LED shows blue when slow charging, violet when fast charging. LED blinks when charging. LED1 stays on when 25% is fully charged. The same is true with the rest 3 LEDs. All 4 LEDs staying on means the power bank is 100% fully charged.

Compatibility: This portable power bank is exclusive designed for LaserPecker engraving machine. Meanwhile can be used to charge portable digital items like smart phones, DC/DV, etc.

Charging Time

Power Adaptor Specification	Charging Time (From 0% to 100%)
5V/3A	6.4 hrs
9V/2A	4 hrs

使用说明

开关机: 按键在机身前立面, 单击开机。指示灯常亮蓝灯。30秒无负载自动关机。

指示灯: 4颗电量指示灯, 每颗对应指示约25%电量, 第一颗指示灯快速闪烁时, 需给移动电源充电。慢充时, 显示蓝灯, 快充时, 显示紫灯。充电时, 指示灯慢闪。充满一格后, 此格灯常亮, 直至4格常亮, 表示电量已充满。

兼容性: 此移动电源专属为啄木鸟移动激光雕刻机使用。同时可以为智能手机, DC/DV等便携式数码产品充电。

充电时间

充电器参数	从0%-100%充满电耗时
5V/3A	6.4小时
9V/2A	4小时

Specification

5200mAh

Output: USB-A 5V/3A
Type-C 5V/2A, Type-C 9V/2A
DC 12V/6A

Input: 5V/3A, 9V2A

Model: LaserPecker PS

Energy: 56.16Wh

Rated capacity: 10.8V 5200mAh

Made in China



E-Mail: support@laserpecker.com



Facebook: LaserPecker

产品规格

产品型号: LaserPecker PS

电芯: 锂离子动力电池

容量: 56.16Wh

容量: 10.8V 5200mAh

输出: 5V/3A, 9V2A

输入: USB-A 5V/3A

Type-C 5V/2A, Type-C 9V/2A

DC 12V/6A

Made in China



E-Mail: support@laserpecker.com