LaserPecker

LaserPecker 2 Versatile Electric Roller **User Manual**



Versatile electric roller

versatile electric rolle

Silicone bands

01 /Accessories List

 Facebook: LaserPecker 2 VIP Group Email: LaserPecker 2 VIP Group

Scan QR code to watch LaserPecker 2 instruction video VIP Group

Tel: +86 0755-28913864

 We offer global online technical support services for this product. If you encounter any problems during your use, please feel free to contact us and we will respond to you as soon



02 /Indicator and Interface Instructions

Port and indicator

Connection indicator

Connection diagram


 Ruler ranging the object.

03 /Ranging Method

1 Mode selection 2 Open the versatile electric roller 3 Select the cylinder mode


engraving position, set proper power/depth and engraving size, then ready to engrave.

This mode is used to engrave on cylindrical objects. Select [cylinder] in APP, set the correct distance 110mm, preview




In [cylinder] mode, if the cylindrical object is frictionless, please wrap silicone bands on it.


1 Wrap two silicone bands on both ends of the object. 2 They'll prevent the object from skidding from the roller.



05 /Engraving Mode - Slab Mode

This mode is used to engrave on long and flat objects. Select [slab] in APP, set the correct distance 110mm, preview engraving position, set proper power/depth and engraving size, then ready to engrave.







engraving position, set proper power/depth and engraving size, then ready to engrave.



















